

CONNECTED

WEAR

by *fibretronic™*

IP30

iPod Controller




wearable technology




CONNECTION INSTRUCTIONS

Connect any CONNECTED-wear Keypad or Joystick controller to the IP30 module using the Jack Plug. Connect the IP30 module to your iPod using the Dock Connector.

CONNECTED-wear
Joystick or Keypad Controller



Jack Plug



iPod

Earphones








IP30 Module



Dock Connector

OPERATING INSTRUCTIONS

To operate the Keypad controller simply press the flexible buttons. To operate the Joystick controller toggle the flexible stick to the right, to the left, upwards or downwards. Push the Joystick in the centre for Play/Pause.

-  **VOLUME +** Press to increase the volume.
-  **FAST FORWARD** Press to skip forward to the next track. Press and hold to fast forward through a track.
-  **PLAY / PAUSE** Press to start and stop the music. Press and hold to turn off the iPod.
-  **REWIND** Press to skip backwards to the previous track. Press and hold to rewind through a track.
-  **VOLUME -** Press to decrease the volume.

CARE INSTRUCTIONS

Please follow the garment manufacturer's care instructions listed on the apparel item. **DO NOT WASH OR DRY CLEAN THE IP30 MODULE.** Disconnect and remove the IP30 module from the garment before cleaning. After washing, ensure the Keypad and Joystick controllers are thoroughly dry before use.



CONNECTED


WEAR

by fibretronic™

IP30

iPod Controller

This IP30 module allows you to control your iPod from your garment or bag. Plug the IP30 module into any product that has a CONNECTED-wear Keypad or Joystick controller.




iPod Compatibility

The IP30 module is compatible with all iPod players except; iPod 1st Generation, iPod 2nd Generation and iPod Shuffle. This is a 'Made for iPod' licensed product.



CONNECTED-wear, by Fibretronic, is a unique system of integrated controls in garments, bags and other soft goods. CONNECTED-wear Keypad and Joysticks can control audio players, mobile phones and other personal electronics. Just select the CONNECTED-wear module of your choice and get CONNECTED....

www.connectedwear.com



iPod is a trademark of Apple Inc., registered in the U.S. and other countries

CONNECTED-wear and Fibretronic are trademarks of Fibretronic Limited